

# Lock Kit Assembly Instructions

**IMPORTANT:** Use caution near sheet metal edges which may be sharp.

**Before You Begin:** Open, identify, and count all parts. Read all instructions.

**Parts:** (A) Lock Bar Attachment, (B) Lock. (C) Keys (2), (D) Spring Clip

**Tools Required:** Hammer, Punch

## Installation:

1) Use a hammer and punch to remove the oval knock-out in the upper right corner of the cabinet. Tap from the outside. **(Figure 1)**

2) Locate the lock bar on the inner right side wall. The lock bar has two horizontal slots at the top. **(Figure 1 & 2)**

3) Insert the lower tab of the Lock Bar Attachment (A) into the bottom slot. Snap the upper tab into the top slot. **(Figure 2)**

4) Insert the Lock (B) and Key (C) through the hole with the pin in the unlocked position. Align to fit the Lock Bar Attachment (A). **(Figure 3)**

5) Inside the cabinet, slide the Spring Clip (D) into the grooves on the lock. **(Figure 3)**

**IMPORTANT:** Key must turn counter-clockwise to lock.

